

Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118

برای دریافت اطلاعات بیشتر به www.Ecu118.ir مراجعه کنید

Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118

www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir

www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir

@Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118

@Ecu118 @Ecu118 **جزوه آموزشی** @Ecu118 @Ecu118 @Ecu118

نقشه های الکتریکی خودرو

www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir

هایما S7 TC

www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir www.Ecu118.ir

@Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118 @Ecu118

@Ecu118 @Ecu118 <https://telgram.me/Ecu118> @Ecu118 @Ecu118

SYSTEM CONTENTS

Ground Point	Y
Electric Harness Schematic	W-1 W-2
Charging System & Starting System	A-1
Start-stop Start-up System	A-2
Engine Control System(1.8T)	B-3a B-3b B-3c B-3d
Transmission Control System(1.8T-6AT)	B-4a B-4b B-4c
Fuel Pump Control System	B-7
Fan control system / Vacuum pump (1.8T)	B-8a
Combination Instrument (1.8T)	C-1a C-1b C-1c C-1d C-1e C-1f
Windshield Wiper And Washer	D-1a D-1c
Rear-window Wiper And Washer	D-1b
Headlamp	E-1
Headlamp Beam Level Adjusting System	E-2
Front/Rear Fog Lamp	E-5
License Plate Lamp/Position Lamp/Tail Lamp/Daytime Running Lamp	E-7
Turn Indicator And Hazard Warning Lamp	F-1
Reversing Lamp	F-2
Brake Lamp	F-3
Horn	F-4
Air Conditioning System	G-1a G-1b

Compressor Control System	G-2
Reversing Radar System	H-1
Rear Vision System	H-2
360 ° imaging system (1.8T)	H-3
Cigarette Lighter / Rear Defroster System	I-1
Illumination Lamp	I-2a I-2b I-2c
Interior Lamp/Reading Lamp/Trunk Lamp	I-3
Sound System	J-1a J-1b
Power Window System	K-1
Remote And Central Door Lock System	K-2a K-2b K-2c K-2d
Exterior Rearview Mirror Heater/Power Exterior Rearview Mirror	L
Sunroof And Auto-dimming Interior Rearview Mirror	M
Anti-lock Braking System	O-1a O-1b
Smart Key System (PEPS)	N-1a N-1b N-1c
Body Control System (BCM)	N-2a N-2b
Power Supply System (Without smart key)	Z-1a Z-1b
Power Supply System (With smart key)	Z-2a Z-2b
Power Seat And Seat Heating	P
Electric Power Steering System (EPS-II)	Q
Air bag/Seat Belt Pretensioner System(1.8T)	S

System Contents

Anti-theft System(1.8T)	T
Diagnosis Link Connector (DLC)(1.8T)	U-1
Communication Wire (CAN)(1.8T)	U-2a U-2b
Fuse Box Wiring Diagram(1.8T)	FB
Common Connector List(1.8T)	X-1 X-2 X-3 X-4
Junction Box Wiring Diagram(1.8T)	JB

General Wire Color Code


Color	Code	Color	Code
Black	B	Light Green	LG
Brown	BR	Orange	O
Dark blue	DL	Pink	P
Dark Green	DG	Red	R
Gray	GR	Sky Blue	SB
Green	G	Violet	V
Light blue	LB	White	W
Blue	L	Yellow	Y

Harness symbol




Name	Symbol	Name	Symbol
Front harness	F	Grounding harness	EA
Engine harness	E	Interior harness	IN
EM harness	EM	Reversing radar harness	RA
Middle harness	D	2# Back door harness	R2#
Rear harness	R	1# Back door harness	R1#
Front left door harness	DR1		
Front right door harness	DR2		
Rear left door harness	DR3		
Rear right door harness	DR4		
Instrument harness	I		

Ground point

Y




Harness mark: (F) (E) (D) (R)






Electric harness schematic (with smart key)

برای دریافت اطلاعات بیشتر به www.Ecu118.ir مراجعه کنید




Charging system / start-up system

A-1




Harness mark: (F) (E) (D) (R)




A-2





Harness mark: (F) (E) (D) (R)





Harness mark:  (F)  (I)  (E)  (EM)  (B3-04)  (B3-05)  (FB)





B3-01 ECU(EM)


B64	B63	B62	B61	B60	B59	B58	B57	B56	B55	B54	B53	B52	B51	B50	B49
B	B	P/G	O/W	L/G	V/L	*	*	V/G	*	G/L	*	*	*	*	*
B48	B47	B46	B45	B44	B43	B42	B41	B40	B39	B38	B37	B36	B35	B34	B33
B/R	W/R	B/Y	L/G/R	P/B	W/L	B/R/Y	W/R	*	G/Y	V/G	W/B	*	*	*	*
B32	B31	B30	B29	B28	B27	B26	B25	B24	B23	B22	B21	B20	B19	B18	B17
V/G	*	V/W	*	V	*	R/G	*	B/L	*	V/B	G/W	V	*	*	L/O
B16	B15	B14	B13	B12	B11	B10	B9	B8	B7	B6	B5	B4	B3	B2	B1
W	W	*	*	O	*	*	G/O	*	L/W	*	W/G	*	*	*	B/G

B3-02 ECU(EM)

B112	B111	B110	B109	B108	B107	B106	B105	B104	B103	B102	B101
B	B	*	G/Y	L/G/Y	V/G	*	V/B	L/G	*	V/R	G/W
B100	B99	B98	B97	B96	B95	B94	B93	B92	B91	B90	B89
B/R	R/Y	V/G	*	V/W	L/W	G/R/B	W/G	*	B/R/W	V/L	B/R
B88	B87	B86	B85	B84	B83	B82	B81	B80	B79	B78	B77
L	O	Y/R	W/R	G/R/Y	*	*	L/W	*	G/R	V	*
B76	B75	B74	B73	B72	B71	B70	B69	B68	B67	B66	B65
L/O	W/Y	V/G	L/O	W/B	L/R	L/B	P/L	R/Y	L/G	*	L/Y

B3-06 1 # fuel injector(EM) 	B3-07 2 # fuel injector(EM) 	B3-08 3 # fuel injector(EM)
B3-09 4 # fuel injector(EM) 	B3-10 Variable cam timing (EM) 	B3-11 Crankshaft position sensor(EM)
B3-12 Rear oxygen sensor(EM) 	B3-13 Front oxygen sensor(EM) 	B3-14 Variable cam timing (EM)


Harness mark: (F) (E) (D) (R)



B-3b


Engine control system (1.8T)

B-3c




B3-02 ECU(EM)



112	111	110	109	108	107	106	105	104	103	102	101
B	B	*	G/Y	LG/Y	Y/G	*	V/B	LG	*	V/R	G/W
100	99	98	97	96	95	94	93	92	91	90	89
B/R	R/Y	Y/G	*	V/W	L/W	GR/B	W/G	*	BR/W	Y/L	BR/R
88	87	86	85	84	83	82	81	80	79	78	77
L	O	Y/R	W/R	GR/Y	*	*	L/W	*	GR	Y	
76	75	74	73	72	71	70	69	68	67	66	65
L/O	W/Y	Y/G	L/O	W/B	L/R	P/L	R/Y	LG	*		L/Y




Harness mark:  (F)  (E)  (D)  (R)





B-3d

[illegible]


Harness mark:  (F)  (E)  (D)  (R)








B4-02 Gearshift plug (I)					
C	LG			B	B/Y
H	LG/B	*	G/R	*	O/B

Harness mark:  (F)  (E)  (D)  (R)




Transmission control system (1.8T-6AT)

B-4b




Harness mark:  (F)  (E)  (D)  (R)




Transmission control system (1.8T-6AT)


B4-C




B4-01 TCU(EM)



B4-04 AT solenoid valve (EM)





Harness mark:  (F)  (E)  (D)  (R)





Fuel pump control system

B-7




Harness mark: (F) (E) (D) (R)




Fan control system / Vacuum pump (1.8T)

B-8a




Harness mark:  (F)  (E)  (D)  (R)



B-8a




Harness mark:  (F)  (E)  (D)  (R)




Combined instrument (1.8T)

C-1b




Harness mark:  (F)  (E)  (D)  (R)



Combined instrument (1.8T)

C-1c



C1-01 Combined instrument (I)

() with ESP

C1-01 Combined instrument (I)

@ with ignition switch

C1-05 Brake fluid level sensor (F)


C1-06 Parking switch (D)

A1	B/Y	B/L	B/W	B/R	R/Y	P	Y/G	(G/O)	(V/W)	*	*	*	*	G/B	L/G/R	G/W	G/R	Y/L	A16
A17	LG	LGB	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	A32


B1	B	B/G	L/O	*	BR/G	\$L/B	\$L/W	G/Y	B/W	GR	GR/Y	Y/R	BR/W	L/R	V	Y/B	B16
B17	BR/Y	Y	@/R	@/V/W	BR/G	*	*	*	*	*	*	*	*	*	*	*	B32



Harness mark:  (F)  (E)  (D)  (R)



C-1c



C1-01 Combined instrument (I)

() with ESP

C1-01 Combined instrument (I)

\$ with PEPS
@ with ignition switch

C1-07 Engine oil pressure switch(E)

A1	A16
B/Y	B/L
B/L	B/W/B/R
LG	R/Y
	P
	Y/G
	(G/O)
	(V/W)
	G/B
	L/G/R
	G/W
	G/R
	Y/L

B1	B16
B	B/G
B/Y	L/O
Y	@R
	@V/W
	B/R/E
	\$L/B
	\$L/W
	G/Y
	B/W
	GR
	GR/Y
	Y/R
	BR/W
	L/R
	V
	Y/B

A17



A32

B17


B32





Harness mark: (F) (E) (D) (R)



C-1d






Harness mark:  (F)  (E)  (D)  (R)






Harness mark:  (F)  (E)  (D)  (R)









Harness mark: (F) (E) (D) (R)




Harness mark: (F) (E) (D) (R)



<https://telgram.me/Ecu118>




Harness mark:  (F)  (E)  (D)  (R)





Headlamp


E-1





6	LW	* L/O	L/G	L/B	L	1
12	*	* L/R	L/G	L/Y	B	7



Harness mark: (F) (E) (D) (R)




Harness mark: (F) (E) (D) (R)






Front/rear fog lamp

E-5






Harness mark:  (F)  (E)  (D)  (R)







Harness mark: (F) (E) (D) (R)







F2-01 Reversing lamp switch (EM)




E7-05 Left trim lamp (tail lamp) (R2#)




E7-06 Right trim lamp (tail lamp) (R2#)

Harness mark: (F) (E) (D) (R)




Brake lamp



F-3



Harness mark: (F) (E) (D) (R)




Harness mark:  (F)  (E)  (D)  (R)




Air conditioning system


G-1a



برای دریافت اطلاعات بیشتر به www.Ecu118.ir مراجعه کنید

Harness mark: (F) (E) (D) (R)





G1-01 A/C control unit (I)




() with ESP

G1-07 Interior temperature sensor (I)


G1-08 Evaporator temperature sensor (I)

G1-09 Temperature control actuator (I)


G1-10 Blowing mode actuator (I)



Harness mark:  (F)  (E)  (I)  (A)  (A)



Compressor control system



G2-01 Electromagnetic clutch (EM)



Electromagnetic clutch

G2-01

Y/G(F)

X-07

FB-05

FB-03


BR/Y(EM)


ECU
(SECTION B-1d)

Main relay
(SECTION B-1a)

Compressor relay

Harness mark:  (F)  (E)  (D)  (R)





1	P/B	R/W	B/W	B/Y	*	BR/R	*	R/Y	*
9	B	P/L	R/L	B/R	B/O	*	*	*	*

H1-01 Reversing radar control unit (IN)


H1-02 Left reversing radar sensor (RA)


H1-03 Middle left reversing radar sensor (RA)

H1-04 Middle right reversing radar sensor (RA)

H1-05 Right reversing radar sensor (RA)


Harness mark:  (F)  (E)  (D)  (R)






H-2


Harness mark:  (F)  (E)  (D)  (R)



<https://telgram.me/Ecu118>



Harness mark:  (F)  (E)  (D)  (R)





<https://telgram.me/Ecu118>

Harness mark: (F) (E) (D) (R)

Front harness (F) - Instrument harness (I)

X-08

X-07

Ignition switch

X-03

Defrosting relay
11-01

Middle harness (D) - Instrument harness (I)

X-06

Junction box (refer to JB)

2# back door harness (R2#) - Middle harness (D)

X-11

Defroster
11-02

10


X-09

2# back door harness (R2#) - Back door harness (R1#)

Defroster
11-03

Cigarette lighter
11-04

Fuse box (refer to FB)



C1-01 Combined instrument (I)

() with ESP

J1-01 Sound unit (I)

N1-01 Start button (I)


A1	B/Y	B/L	B/W	E/R	N/Y	P	Y/G	(G/O)	(V/W)	*	*	*	G/B	LG/R	G/W	G/R	Y/L	A16
A17	LG	LG/B	*	*	*	*	*	*	*	*	*	*	*	*	*	*	*	A32


Yellow C1				Green C2				Blue C3			
R/B	G	B/G	GR/B	R/Y	GR/W	Y	*	R/B	G	B/G	GR/B
3	*	6	*	9	*	12	*	3	*	6	*
R/L	G/Y	L/O	*	R/L	G/Y	L/O	*	R/L	G/Y	L/O	*

A2	R/W	R/G	A1	B2	O	L	B1
Black	G	LG/B		Brown	G/Y	G/R	
A8	LG	*		B8	LG/W	G/O	
B	BR/Y	A7		B7	L/Y	L/W	

10	R	P	R/B	LG/B	LG	6
5	P	W	G/B	*	*	1

Harness mark: (F) (E) (D) (R)







D1	D10
LG	GRL
L/R	*
L/W	*
R/G	*
L	*
O	*
R/B	*
W/R	*
Y/B	*
W/L	*
R/L	*
Y	*
Y/G	*
L/Y	*


S	Q	O	M	K	I	G	E	C	A
R/B	LG	L/W	L	L/O	L/B	V	R/G	R/Y	B
B	P	G/B	P/L	W	*	*	*	*	B
T	R	P	N	L	J	H	F	D	B




LG	Y	B/Y
LG/B	*	*
G/R	*	O/B

Harness mark: (F) (E) (D) (R)






1-2c




12-02 Cigarette lighter illumination (D) 	12-03 Ignition switch illumination (I) 	P2-05 Seat heating switch (D) 
F1-01 Hazard warning lamp switch illumination (I) 		

Harness mark:  (F)  (E)  (D)  (R)







Harness mark:  (F)  (E)  (D)  (R)




J-1a





Harness mark:  (F)  (D)  (E)  (R)



J-1a




Harness mark: (F) (E) (D) (R)






Power window system

K-1




Harness mark: (F) (E) (D) (R)



Remote and central door lock system


K-2a



M	*	GR/L	*	GR/R	*	OW	R/W	V	A
B	*	GR/L	*	GR/R	*	OW	R/L	*	B

A1	*	BR/W	*	R/L	R/B	BR	*	A7
A8	*	BR/W	*	R/L	R/B	BR	*	A14

B1	*	V/B	V/W	V/R	GR/L	V/B	*	B6
B7	*	V/G	GR/R	V/W	V/B	V/B	*	B12




Harness mark: (F) (E) (D) (R)



Middle harness (D) - Instrument harness (I)

X-08


Central door lock unit K2-01



Junction box (refer to JB)




Fuse box (refer to FB)



Central locking switch F1-01



Harness mark: (F) (E) (D) (R)





K-2b




	A	B	C	D	E
	B	*	L/R	*	*

Harness mark:  (F)  (E)  (D)  (R)








Harness mark: (F) (E) (D) (R)



7




Harness mark: (F) (E) (D) (R)





Sunroof and auto-dimming interior rearview mirror (with tire pressure and reversing distance display)

M





Harness mark: (F) (E) (D) (R)






Harness mark: (F) (E) (D) (R)






Anti-lock braking system (1.8T)

O-1b




Harness mark: (F) (E) (D) (R)







N1-01 Start button (I)




N1-02 PEPS controller (I)



N1-03 PEPS relay box (I)




Harness mark:  (F)  (D)  (I)  (X-03)








Harness mark: (F) (E) (D) (R)




N-10



Harness mark:  (F)  (E)  (D)  (R)



N-1c





N2-01 Body control system (BCM) (I)


K2-02 FL door lock actuator (DR1)

K2-05 FR door lock actuator (DR2)

\$ with PEPS




Harness mark: (F) (E) (D) (R)




Body control system (BCM)

N-2b




Harness mark: (F) (E) (D) (R)





Power supply system (without smart key)

Z-1a




Harness mark:  (F)  (E)  (D)  (R)






Z-1a

Power supply system (without smart key)

Z-1b











N1-02 PEPS controller (I)

N1-03 PEPS relay box (I)




Harness mark:  (F)  (D)  (I)  (X)






Harness mark:  (F)  (E)  (D)  (R)






Power seat and seat heating

P




Harness mark:  (F)  (E)  (D)  (R)







Harness mark: (F) (E) (D) (R)




S-1

Harness mark: (F) (E) (D) (R)






Harness mark:  (F)  (I)  (D)  (T)  (X)  (4)  (FB)  (JB)  (T)  (X)  (4)  (FB)  (JB)



Diagnosis link connector (DLC)(1.8T)

U-1a



U-01 Diagnosis link connector (DLC)-1 (EM)

B	*	*	*	*	*	G	
*	*	*	*	*	*	L	Y
*	*	*	*	*	*	L/O	B/G
*	*	*	*	*	*	W/R	*


Note: view from the harness terminal

U-02 Diagnosis link connector (DLC)-2(I)

BR/Y	*	L/O	*	L/G	L	P/B	*
LG	*	B/G	B	B	Y	L/B	*

Note: view from the harness terminal



Harness mark:  (F)  (E)  (D)  (R)




Communication wire (CAN)(1.8T)

U-2c

Diagnosis link connector (DLC)-2




U-01 Diagnosis link connector (DLC)(EM)




Note: view from the harness terminal

U-02 Diagnosis link connector (DLC)-2(I)




Note: view from the harness terminal


U-03 BD CAN Hubs




Harness mark: (F) (E) (D) (R)




U-2c




Harness mark:  (F)  (I)  (X)  (D)  (EM)  (FB)






Fuse box (1.8T)



No.	Fuse name	No.	Fuse name	No.	Fuse name	No.	Relay name
1	Blower	11	PEPS 1	21	Headlamp low-beam	31	Fan
2	AT(TCU B+)	12	Power seat(main)	22	Front fog lamp	32	Start
3	BTN	13	PEPS 2	23	Position lamp	33	Main relay
4	*	14	EBS	24	HORN	34	Headlamp
5	Vacuum pump	15	LCM	25	AC 1	35	Vacuum pump
6	ABS 2	16	Hazard warning lamp	26	*	36	Front fog lamp
7	Main relay	17	Brake lamp	27	*	37	Position lamp
8	Fuel pump	18	Defrost	28	*	38	Compressor
9	Fan	19	ABS 1	29	*	39	Horn
10	IG KEY	20	Headlamp high-beam	30	Main fuse	40	Fuel pump



Fuse box (1.8T)

FB-01 Engine harness (E) A B/W	FB-02 Engine harness (E) A R	FB-04 Front harness (F) K I C A LG/R G/O W L/B R/B G R L/R L/R B B H G F E D B	FB-07 Engine harness (E) * * * * D B
FB-03 EM harness (EM) K I C A FY W GW W W/R * W/G LG L/R BR/V L J H F D B	FB-06 Front harness (F) M K I C A \$BR * * B/R R R L/B B W/G \$P &Y L L H G F E D B		
FB-05 Front harness (F) O M K E C A B/L Y G/R R/L W/B W/B R * G/B Y/G Y/R * W L J I H G F D B	FB-06 Front harness (F) M K I C A \$BR * * B/R R R L/B B W/G \$P &Y L L H G F E D B		

\$ with PEPS

& with start-stop

\$ with PEPS
& with start-stop


Common connector list (1.8T)

X-1


X-01 Front harness (F) - Instrument harness (I) (F) (I)	X-02 Front harness (F) -Middle harness (D) (D) (F)
X-03 Ignition switch (I) & with start-stop (I) X-04 Engine harness (E) - EM harness (EM) & with start-stop (EM) (E)	
X-05 EM harness (EM) - Instrument harness (I) (EM) (I)	

Common connector list (1.8T)


X-06 Middle harness (D) - Instrument harness (I)



X-08 Middle harness (D) - Instrument harness (I)




X-07 EM harness (EM) - Front harness (F)




< > with AT

X-09 1# back door harness (R1#) -2# back door harness (R2#)



X-10 Middle harness(D) -2# back door harness (R2#)




* with reversing camera
& with 360° imaging system


X-2

Common connector list (1.8T)


X-15 Middle harness (D) -Rear right door harness (DR4)




X-16 Middle harness (D) - Reversing radar harness (RA)




X-17 Middle harness (D) -Interior harness (IN)




X-19 Middle harness (D) -Instrument harness (I)




X-20 Middle harness (D) -Instrument harness (I)




X-21 Middle harness (D) -Instrument harness (I)




X-22 Instrument harness (I) -Front harness (F)



X-23 Engine harness (E) -EM harness (EM)





Junction box (1.8T)

JB-01 Instrument harness (I)	JB-02 Middle harness (D)	() with ESP
JB-03 Middle harness (D)		
JB-04 Middle harness (D)		
JB-05 Middle harness (D)		

No.	Fuse name	Fuse	No.	Fuse name	Fuse
1	S/W/RM	15A	10	TCU	10A
2	—	20A	11	DOOR LOCK	30A
3	RADIO	15A	12	P/WIND	30A
4	AC 2	15A	13	WIPER	20A
5	R WIPER	10A	14	ENGINE	10A
6	PEPS_ABS	7.5A	15	METER	10A
7	—	—	16	—	—
8	ROOM	10A	17	P/WIND	30A
9	MIR/DEF	10A			

JB