## **HYUNDAI OBDII DTC**

P1100	Manifold Absolute Pressure Sensor Range/Performance
P1102	Manifold Absolute Pressure Sensor Circuit Low Input
P1103	Manifold Absolute Pressure Sensor Circuit High Input
P1123	Lang Term Fuel Trim Adaptive Too Lean
P1124	Long Term Fuel Trim Adaptive Too Rich
P1127	Long Term Fuel Trim Multiplier Too Rich
P1128	Long Term Fuel Trim Multiplier Too Lean
P1134	HO2S Bank 1 Sensor 1 Transition Time Switch (Bank 1 Sensor I)
P1154	HO2S Bank 2 Sensor 1 Transition Time Switch (Bank 2 Sensor 1)
P1166	HO2S Bank 1 Sensor 1 Controller Adaptive Diagnosis Fault (Bank 1)
P1167	HO2S Bank 1 Sensor 1 Controller Adaptive Diagnosis Fault (Bank 2)
P1168	HO2S Bank 1 Sensor 1 Heater Power Incorrect (Bank 1 Sensor 2)
P1169	HO2S Bank 1 Sensor 1 Heater Power incorrect (Bank 2 Sensor 2)
P1372	Segment Time Incorrect
P1400	Manifold Differential Pressure Sensor Circuit
P1440	EVAP System Vent Solenoid Circuit
P1443	EVAP System Fault (Fuel Tank Cap Missing)
P1510	Idle Control Valve Opening Circuit Shorted (Coil 1)
P1511	Idle Control Valve Command Signal Shorted (Coil 2)
P1513	Idle Air Control Valve Opening Coil Circuit Open (Coil 1)
P1521	Power Steering Switch Input Circuit
P1529	Customer Snapshot Request VIA CAN
P1552	Idle Air Control Valve Closing Coil Circuit Shorted
P1553	Idle Air Control Valve Closing Coil Circuit Open
P1586	Encoding Signal Circuit Not Rationale
P1602	Serial Communication Fault with Transmission Control Unit
P1605	Rough Road Sensor Circuit
P1606	Rough Road Sensor Circuit Not Valid
P1611	MIL Request Signal Circuit Low Input
P1613	ECU Self-Test Failed
P1614	MIL Request Signal Circuit High Input
P1616	Main Relay Fault
P1623	Diagnostic Lamp Power Stage Fault
P1624	MIL On Request Signal//Cooling Fan Relay Low Circuit
P1625	Cooling Fan Relay High Circuit
P1665	Power Stage Group 'A' Fault
P1670	Power Stage Group 'B' Fault